

Silent Feature

- A double walled unit mounted on a sturdy angle iron frame.
- Inner and outer made of heavy MS sheet with outer duly hammertoe painted and inner with high temperature aluminum paint.
- The gap between two walls is filled with high-grade mineral wool to minimize thermal loss.
- Brackets to support the heavily laden drying trays at adjustable height are provided on the sides of inner walls.
- A separate control panel is fitted to the chamber with individual control for ON / OFF and air circulating fan.
- Supplied with
- aluminum trays of size 80 x 40 x 3cm as per tray capacity of unit.
- Indicator cum Controller.

Industrial Tray Dryer



| Model | SNS-TD-24 |
|---------------------------|--|
| Make | SN Solutions |
| No. of Trays | 24 Nos |
| Temperature Range | +5°C Ambient to 250°C |
| Temperature Controller | Digital PID Controller |
| Adjustable Height Provide | Yes |
| Display | LED / LCD / HMI Touch Screen Display |
| Load Approx | 8.0 KW |
| Inner Material | Stainless Steel 304 Grade |
| Outer Material | Stainless Steel 304 Grade / Mild Steel Powder Coated |
| Shelves Materiale | Stainless Steel 304 Grad |
| Dimension (W*D*H) | 900*900*1200 mm |